

EventCount (Event_Info_Group)

Purpose

This function returns the total number of events configured in the system.

Parameters

None

Returns

Return value: **value**

Type: **integer**

Example

Sample Code
None