

Legacy Z-Wave

Information on using the Legacy Z-Wave plugin, version 3.0.6.0 or earlier.

[Displaying Status of Two Sensors with One Icon \(HS3\)](#)

[Adding and Removing Z-Wave Devices](#)

[Adding a Z-Wave Controller](#)

[Erasing a Z-Wave Controller](#)

[Importing Z-Wave Devices](#)